



2QEX with connector



2QEX with cable



Installation guide

This Installation Guide is valid only for encoder types 2QEX with connector and cable gland.



For your safety please read this guide carefully.

Failure to follow the instructions in this guide will render **ALL** certifications **INVALID**.

Installation of the encoder must be completed by a skilled technician or engineer. Failure to comply with the instructions below will render all certifications **INVALID**. **The encoder may not be modified by the customer.**

1. Insure that power is off.
2. Connect to earth prior to proceeding. Observe precautions for handling **ESD** (ElectroStatic Discharge) sensitive devices.
3. The protective caps must be fitted immediately following separation of the plug and socket.
4. Precautions must be taken to avoid dust from forming layers on the encoder.
5. It is strongly recommended that the original packaging be used for any additional shipping or transport.

Caution

- **DO NOT** connect encoder when power is on.
- **DO NOT** separate when energized. (for versions with connector)
- **DO NOT** connect output wires to supply voltage.
- **DO NOT** strike encoder with hammer or any other heavy object.
- If encoder is mounted to electrical machinery with high current or high voltage on the shaft, precautions must be taken for galvanic separation.
- Maintenance is not necessary. Any required maintenance or repair is to be done **only** by the manufacturer.
- To minimize the risk from electrostatic discharge - clean only with a damp cloth.

Marking:



II 3 G Ex nA IIC T4 Gc
 II 3 D Ex tb IIIC Tmax100°C Dc
 Ambient temperature range: – 40°C to +70°C
 Ambient temperature range: – 40°C to +xx°C (for encoders with Rota connector upper ambient temperature can vary but the max. is 60°C).

1) It is place for the specific number for the QAN issuer

Certification numbers:

ITS08ATEX42972 X
 IECEX ITS 15.0035 X

See certifications at www.scancon.dk

The encoder complies with the following standards:

IEC 60079-0: 2017 Ed. 7 EN 60079-0 :2018	Explosive atmospheres - Part 0: Equipment – General requirements
IEC 60079-15 :2010 Ed. 4 EN 60079-15 :2010	Explosive atmospheres - Part 15: Equipment protection by type of protection "n"
IEC 60079-31 :2013 Ed. 2 EN 60079-31 :2014	Explosive atmospheres - Part 31: Equipment dust ignition protection by enclosure "t".

NOTE: Adding and/or removing data (on other CB request) and changing layout to this Installation Manual which does not conflict with the actual data in this document and ATEX/IECEX certification will not require to be notified by Certification Body even though the change will affect the revision number.